



Bottom Case

Tools

This procedure requires the following tools:

- #00 and #000 Phillips screwdrivers (magnetized)
- Black stick (nylon probe 922-5065) or other non-conductive nylon or plastic flat-blade tool
- Multi-compartment screw tray (such as a plastic ice cube tray)

Preliminary Steps

This procedure requires placing the unit upside down on its display housing. Always use a clean, debris-free static mat to avoid scratches and other cosmetic damage to the unit.

Part Overview

