

25 12. Apply *OMC Triple-Guard* grease to washer and shaft. Place washer on shaft.

26 13. Position the steering gear in the steering housing. The pinion gear and steering gear must be indexed using marks **A**.

27 14. Apply *OMC Screw Lock* to steering cable set screw. Position steering cable and install set screw.

15. Install the driver on top of pinion gear.

16. Connect all leads following wiring diagram at the end of this Section. Be careful to observe wire routing and clamp locations.

28 17. Install steering housing cover. When correctly indexed, the direction indicator should point away from the propeller.

29 18. Install four retaining screws and tighten securely.

