

Outboard Models Covered in This Service Manual

2 thru V-6 Models



2 Models

E2RCO

J2RCO

4 Models

E4BRCO
E4BRLCO

E4BRHCO
E4BRHLCO

J4BRCO
J4BRLCO

J4BRHCO
J4BRHLCO

4 Deluxe Models

E4RDCO
E4RDLCO

E4RDHCO
E4RDHLCO

J4RDCO
J4RDLCO

J4RDHCO
J4RDHLCO

5 Models

E5RHCO
E5BFCO
E5BFLCO

J5RHCO
J5BFCO
J5BFLCO

6 Models

E6BACO
E6BALCO
E6BFCO
E6BFLCO

E6RCO
E6RLCO
E6SLCO

J6BACO
J6BALCO
J6BFCO
J6BFLCO

J6RCO
J6RLCO
J6SLCO

8 Models

E8RCO
E8RLCO
E8BACO

E8BALCO
E8SRLCO

J8RCO
J8RLCO
J8BACO

J8BALCO
J8SRLCO

9.9 Models

E10RCO
E10RLCO
E10BACO

E10BALCO
E10SELCO
E10ECO
E10ELCO

J10RCO
J10RLCO
J10BACO

J10BALCO
J10SELCO
J10ECO
J10ELCO

15 Models

E15RCO
E15RLCO
E15ECO

E15ELCO
E15BACO
E15BALCO

J15RCO
J15RLCO
J15ECO

J15ELCO
J15BACO
J15BALCO

20 Models

E20CRCO
E20CRLCO
E20ECO
E20ELCO
E25BECO
E25BELCO
E20BFCO
E20BFLCO

E25BFCO
E25BFLCO
E20BICO
E20BILCO

J20CRCO
J20CRLCO
J20ECO
J20ELCO
J25BECO
J25BELCO
J20BFCO
J20BFLCO

J25BFCO
J25BFLCO
J20BICO
J20BILCO