


























① GEN INFO 	② INSP ADJ 	
③ CHAS 	④ POWR TR 	
⑤ ENG 	⑥ COOL 	
⑦ CARB 	⑧ ELEC 	
⑨ SPEC 	⑩ OPT 	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	
⑰ 	⑱ 	⑲ 
⑳ 	㉑ 	㉒ 
㉓ 	㉔ 	㉕ 

0E031

## ILLUSTRATED SYMBOLS (Refer to the illustration)

Illustrated symbols ① to ⑩ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Periodic inspection and adjustment
- ③ Chassis
- ④ Power train
- ⑤ Engine overhaul
- ⑥ Cooling system
- ⑦ Carburetion
- ⑧ Electrical
- ⑨ Specifications
- ⑩ Optional kit

Illustrated symbols ⑪ to ⑰ are used to identify the specifications which appear.

- ⑪ Filling fluid
- ⑫ Lubricant
- ⑬ Tightening
- ⑭ Wear limit, clearance
- ⑮ Engine speed
- ⑯ Special tool
- ⑰ Ω, V, A

Illustrated symbols ⑱ to ㉕ in the exploded diagram indicate grade of lubricant and location of lubrication point.

- ⑱ Apply locking agent (LOCTITE®)
- ⑲ Apply engine oil
- ⑳ Apply gear oil
- ㉑ Apply molybdenum disulfide oil
- ㉒ Apply wheel bearing grease
- ㉓ Apply low-temperature lithium-soap base grease
- ㉔ Apply molybdenum disulfide grease
- ㉕ Apply Yamabond No.5®