

IMPORTANT INFORMATION

Section 1A - General Information

**1
A**

Table of Contents

How To Use This Manual	1A-2	Decal Application	1A-5
Page Numbering	1A-2	Decal Removal	1A-5
Introduction	1A-3	Instructions for "Wet" Application ...	1A-5
Special Product Information	1A-3	Painting Procedures	1A-7
Directional References	1A-3	Cleaning & Painting Aluminum	
Propeller Rotation	1A-4	Propellers & Gear Housings	1A-7
Serial Number Locations and			
Engine Designation Decal	1A-4		
Sterndrive Unit Serial Number			
Location	1A-5		