

# Contents

---

## REPAIRS & OVERHAUL

### Engine and Associated Systems

In-car engine repair procedures	Page	<b>2A•1</b>
General engine overhaul procedures	Page	<b>2B•1</b>
Cooling, heating and air conditioning systems	Page	<b>3•1</b>
Fuel and exhaust systems	Page	<b>4•1</b>
Engine electrical systems	Page	<b>5•1</b>
Engine management and emission control systems	Page	<b>6•1</b>

### Transmission

Manual transmission	Page	<b>7A•1</b>
Automatic transmission	Page	<b>7B•1</b>
Clutch and driveline	Page	<b>8•1</b>

### Brakes

Braking system	Page	<b>9•1</b>
----------------	------	------------

### Suspension

Suspension and steering systems	Page	<b>10•1</b>
---------------------------------	------	-------------

### Body Equipment

Bodywork and fittings	Page	<b>11•1</b>
-----------------------	------	-------------

### Electrical

Body electrical systems	Page	<b>12•1</b>
-------------------------	------	-------------

### Wiring Diagrams

Page **12•10**

## REFERENCE

### MOT Test Checks

Checks carried out from the driver's seat	Page	<b>REF•1</b>
Checks carried out with the vehicle on the ground	Page	<b>REF•2</b>
Checks carried out with the vehicle raised	Page	<b>REF•3</b>
Checks carried out on your vehicle's exhaust emission system	Page	<b>REF•4</b>
Tools and Working Facilities	Page	<b>REF•5</b>
General Repair Procedures	Page	<b>REF•8</b>
Fault Finding	Page	<b>REF•9</b>
Conversion factors	Page	<b>REF•17</b>
Automotive chemicals and lubricants	Page	<b>REF•18</b>
Buying spare parts and vehicle identification numbers	Page	<b>REF•19</b>
Glossary of Technical Terms	Page	<b>REF•20</b>

### Index

Page **REF•25**